

TB110

HW

How much the maximum capacity of the micro SD Card Reader can be supported?

The maximum capacity of the micro SD Card Reader is 128GB.

How many Indicator LED of TB110 & how to works?

3 LED (Battery, Power , Front camera)

Battery : Charging state red light, full of light out

Power : Green light for system startup status

Front camera : The front camera work lights up white

How to close the camera function?

1. Connect a USB keyboard to the TB110.
2. Power on TB110 and press the delete button on the keyboard.
3. Entry to the BIOS setting interface, please follows the below setting:

Advanced→ Others→ Camera→Disabled.

4. Press the F4 button (Save & Exit) of the keyboard → press Yes



OS

How to auto power on TB110 without press the power button when TB110 inside the kiosk?

1. Connect a USB keyboard to the TB110.
2. Power on TB110 and press the delete button on the keyboard.
3. Entry to the BIOS setting interface, please follows the below setting:
Advanced→ Others→ AC automatic Power On→ Change Disabled to Enabled.
4. Press the F4 button (Save & Exit) of the keyboard → press Yes

How to know the O.S version of TB110?

Settings→System→About→Windows specifications

How to reset TB110?

Settings→update & Security→Recovery→Reset this PC

How to Restore Hard Disk Image on TB110?

Please follow the SOP to restore the O.S and download the O.S from the below link:

http://download1.tw.ute.com/cs/firmware/TB110/TB110_Restore_HDI_SOP_20210616.pdf

http://download1.tw.ute.com/cs/firmware/TB110/E7251U1_IoT_RS5_EN_TW_R.FD.00.52.04_20210423.zip

